


MAR-2120

An integrated PIR sensor and lamp-holder format for automatic retrofit lighting.



INSTALLATION ARRANGEMENT

NTS - NOT TO SCALE



VERIFIED PRODUCT DATA

SENSOR TYPE	Passive infrared (PIR)
FORMAT	Integrated sensor lamp holder
CONFIGURATION	Lamp base and electrical limits require confirmation

INSTALLATION SEQUENCE

- 1 Isolate the circuit and confirm lamp base, supply voltage and permitted lamp load.
- 2 Mount the holder securely with the sensor lens facing the intended detection area.
- 3 Install a compatible lamp without exceeding the approved electrical limits.
- 4 Restore power and test motion response, delay and daylight behavior.

INSTALLER CHECK

Use the approved production wiring and dimensional drawing before cutting or energizing.